

# ALCOLOCK™ V3

Alcohol Ignition Interlock

Available through:



## Alcohol Countermeasure Systems

60 International Boulevard  
Toronto, Ontario M9W 6J2 CANADA

+1 416 619 3500

[acs-corp.com](http://acs-corp.com)

Designed in Canada by  
Alcohol Countermeasure Systems Corp



## Warranty

All ACS alcohol ignition interlocks are warranted to be free from defects in workmanship and material for one year from the date of purchase. Only qualified technicians should perform maintenance on any alcohol ignition interlock.

ACS, ALCOHOL COUNTERMEASURE SYSTEMS, ALCOLOCK, ALCOOSIM and the "Molly" are trademarks of Alcohol Countermeasure Systems (International) Inc. and are used under license.

20180301





Secure and reliable commercial risk management

ALCOLOCK V3 alcohol interlocks are designed for commercial environments, featuring proven durability and testing features. The device inhibits vehicle operation if the driver has been drinking.

### Quality engineering

ALCOLOCK V3 alcohol interlocks are engineered to withstand the vibration, dirt, dust, humidity and extreme temperatures typically found in commercial applications. They can be installed in any motorized equipment, including trucks, ships, trains and heavy machinery.

### Simple breath sampling

Drivers use the handset to provide a breath sample. Within seconds the ALCOLOCK V3 device analyses it for breath alcohol content (BrAC) and displays instructions to the driver. Sensors help ensure mechanical devices such as air pumps cannot be used to circumvent the system.

### Programmable

Drivers may be tested at the beginning of their shift or at intervals throughout the day. The ALCOLOCK V3 system can be programmed to meet company safety policy requirements. Proprietary software allows reporting and logging of breath test results, times, dates and more.

### Emergency override

ALCOLOCK V3 devices include an electronic override for emergency situations. Its use may be monitored using the system software, ensuring the ALCOLOCK V3 is being allowed to perform its primary function.

## ALCOLOCK V3 with Wi-Fi

ALCOLOCK V3 with Wi-Fi is the latest technology in the series of alcohol interlocks for commercial vehicles.

### Wireless data transmission

Event log data is automatically transmitted from the ECU whenever the vehicle comes in range and is authenticated by the fleet Wi-Fi base station. Fleet managers can access the data online via a secure network application.

### Secure data handling

Event log files and communication are protected with AES 128 bit encryption standard for security of the memory and the transmission of data files. Flash memory preserves the event log when the vehicle battery is disconnected.

### Focus™ camera option<sup>1</sup>

ALCOLOCK V3 allows for positive identification of the driver each time a breath sample is given. ALCOLOCK V3 triggers the mounted camera to take an image at the time of the test - the image is then time stamped and stored in a database to view.



1. The Focus camera is optional for the Wi-Fi version.

2. Data can be transferred via Wi-Fi, Bluetooth, GPRS or telematics, depending on the model purchased. All devices can manually transfer data through a download station.

-  **Sensor**  
Electrochemical
-  **Specificity**  
Alcohol only; no response to ketones or hydrocarbons
-  **Range of measurement**  
0 to 500 mg/dL
-  **Analysis time**  
5 to 25 seconds
-  **Recycle time**  
10 to 30 seconds
-  **Accuracy**  
±5 @ 50 mg/dL
-  **Display**  
Graphic LCD
-  **Memory**  
100,000 logged events
-  **Data transfer<sup>2</sup>**  
Wi-Fi 802.11 BGN
-  **Operating temperature**  
-40 °C to +85 °C
-  **Operating voltage**  
12 or 24 volt DC
-  **Calibration**  
ALCOSIM™ breath alcohol simulator or equivalent
-  **Dimensions**  
150 mm x 48 mm x 50 mm
-  **Weight**  
220 grams
-  **Certification**  
CENELEC EN 50436-2